




Kit 1524

KIA Soul, 5-dr Hatchback, 08- / *10-


***North America**



754 Rapid System
480R Rapid Traverse (North America)



480 Traverse (North America)



THULE[®]
SWEDEN

ISO 11154-E

754 Rapid System **x1**

480R Rapid Traverse (North America) **x1**

754 Rapid System **x4**

480R Rapid Traverse (North America) **x4**

754 Rapid System **x4**

480R Rapid Traverse (North America) **x4**











				
				
				
				
				
				

Diagram illustrating the assembly of the front panel components:

- Component 1030 (x 2)
- Component 1031 (x 2)
- Component 290 (x 4)
- Control Panel (x 1)



1





2





754 Rapid System
480R Rapid Traverse
(North America)



x4





x4



x4




480 Traverse
(North America)




x4

3



754 Rapid System




X

KIA Soul, 5-dr Hatchback, 08-/*10-

X

38




Y

KIA Soul, 5-dr Hatchback, 08-/*10-

Y

36,5

3



480R Rapid Traverse



480 Traverse



(North America)



X inch/mm



KIA Soul, 5-dr Hatchback, 08-/*10-

X inch

X mm

40 1/2"

1031 mm



Y inch/mm



KIA Soul, 5-dr Hatchback, 08-/*10-


Y inch

Y mm

40"



1016 mm

4




5


KIA Soul, 5-dr Hatchback, 08- / *10-




6





i



A



B



KIA Soul, 5-dr Hatchback, 08- / *10-

X mm

Y mm

X inch


Y inch

265 mm


760 mm

10 1/2"

30"



7



GB/US Tighten alternately
D Die Schrauben abwechselnd anziehen
F Serrer alternativement chaque côté
NL Afwisselend aan de linker- en de rechterkant aandraaien
I Alternare il serraggio delle viti
E Apretar alternativamente
PT Aperte alternadamente
S Dra åt växelvis
FIN Kierrä vuorotellen
EST Pinguldage vaheldumisi
LAT Pieļieciet pamišus
LIT Užsukinėkite pakaitomis
PL Śruby dokręcaj naprzemiennie
RU Затягивайте попеременно





CZ Pokręťta багаžníka dokręcaj dokręcaj naprzemiennie.
SK Dofahujte striedavo
SLO Privijajte izmenično.
HR Naizmjenočno zategnite
HU Egyarástól fűggetlenül szorítandó
GR Σφιγγεται εναλλάξ
TR Dönüşümlü sıkın

中文 交替拧紧



한국어 번갈아 가며 조이십시오.

日本語 交互に締め付けてください。

ไทย ชันในแบบสลับ




≈ 3 Nm





8



x1
17 mm





THULE
SWEDEN

**ONE
KEY
SYSTEM**

544 (x4)

596 (x6)

588 (x8)

NA **510** (x10)

EUR **452** (x12)

ASIA