




Kit 1562


HONDA Insight, 5-dr Hatchback, 09–



754 Rapid System
480R Rapid Traverse (North America)



480 Traverse (North America)



THULE[®]
SWEDEN

ISO 11154-E

Max.
50 kg
Max.
110 lbs

Kit XXXX
instructions
THULE

x1

754 Rapid System
480R Rapid Traverse (North America)

x1

480 Traverse (North America)

x2

x2 23 mm
x2 23 mm
x4
x4

x1 17 mm
x2 23 mm
x2
x4


x2 23 mm
x2

x2

999 **x2**
1041 **x2**
140 **x2**
141 **x2**

RR **FR**
FL **RL**
x1



1





2





754 Rapid System
480R Rapid Traverse
(North America)



x4





x4



x4




480 Traverse
(North America)




x4

3




754 Rapid System



HONDA Insight, 5-dr Hatchback, 09–

X

40




HONDA Insight, 5-dr Hatchback, 09–

Y

38

3



480R Rapid Traverse



480 Traverse



(North America)



X inch/mm



HONDA Insight, 5-dr Hatchback, 09–

X inch


X mm

41 ³/₄ "

1060 mm



Y inch/mm



HONDA Insight, 5-dr Hatchback, 09–


Y inch

Y mm

40 ³/₄ "



1035 mm

4




5


HONDA Insight, 5-dr Hatchback, 09–




6





i



A



B



HONDA Insight, 5-dr Hatchback, 09–

X mm

Y mm

X inch





Y inch

325 mm


750 mm

12 ³/₄ "

27 ¹/₂ "







7





GB/US Tighten alternately
D Die Schrauben abwechselnd anziehen
F Serrer alternativement chaque côté
NL Afwisselend aan de linker- en de rechterkant aandraaien
I Alternare il serraggio delle viti
E Apretar alternativamente
PT Aperte alternadamente
S Dra åt växelvis
FIN Kierrä vuorotellen
EST Pinguldage vaheldumisi
LAT Pieļieciet pamišus
LIT Užsukinėkite pakaitomis
PL Śruby dokręcaj naprzemiennie
RU Затягивайте попеременно

CZ Pokręťta багаžníka dokręcaj dokręcaj naprzemiennie.
SK Dofahujte striedavo
SLO Privijajte izmenično.
HR Naizmjenočno zategnite
HU Egyarástól fűggetlenül szorítandó
GR Σφιγγετε εναλλάξ
TR Dönüşümlü sıkın

中文 交替拧紧
한국어 번갈아 가며 조이십시오.
日本語 交互に締め付けてください。
ไทย ชั้ในแบบสลับ





≈ 3 Nm





8



x1
17 mm





THULE
SWEDEN

**ONE
KEY
SYSTEM**

544 (x4)

596 (x6)

588 (x8)

NA 510 (x10)

EUR 452 (x12)

ASIA